

Snorkel S3370RT SCISSOR LIFT

OPERATING INSTRUCTIONS & SPECIFICATIONS

Quick Start Guide

The ground control station and platform control station emergency stop buttons (RED) must be set to "ON" in order to operate this machine.

1. Operating from Ground Controls

- **Starting Unit** – Set the battery switch to the on position. The emergency stop switch should be pulled out. Set the ground/platform switch to "ground". If unit is cold, press the glow plug switch down for no more than 20 seconds. Press and hold the start switch down until engine starts
- **Raising/Lowering the Platform** – **To raise the platform**, press and hold the Lift/Lower switch **up** while holding the "enable" switch down. **To lower the platform** – press and hold the Lift/Lower switch **down** while holding the "enable" switch down

2. Operating from Platform Controls

- **Starting Unit** – Set the battery switch to the "on" position. The emergency stop switch should be pulled out. Set the ground/platform switch to "platform". Enter the platform and close the gate. If unit is cold, press the glow plug switch down for no more than 20 seconds. Press and hold the **START** switch down until the engine starts.
- **Driving the Unit** – Set the SPEED switch to turtle (slow) until comfortable increasing the speed. Set the Lift/Drive selector switch to DRIVE. Squeeze and hold the Safety Control against the joystick controller.
To go forward, push the joystick controller forward.
To go in reverse, pull the joystick controller toward you.

To steer the unit, press and hold the controller rocker switch (located on the top of the joystick) on the left side to turn left. Press and hold the rocker switch on the right side to turn right.

- **Raising/Lowering from platform** – Set the Lift/Drive selector to LIFT. **To raise the platform**, squeeze the safety control against the joystick and pull backward. **To lower the platform** – squeeze the safety control against the joystick and push forward.
- **Operating the Stabilizers** – The engine must be running and set for platform operation. **Auto Leveling** - The Joystick trigger must be squeezed while operating the stabilizer switches. Press and hold the middle switch on the unit diagram in the **DOWN** position until all movement stops or the “Lift Enable Light” illuminates. It will illuminate if all 4 feet are on the ground and the machine is level. To Auto Raise the stabilizers, make sure the platform is fully lowered, and press **UP** on the middle switch.
You can manually control each stabilizer by moving the switches located at each corner.

SNORKEL S3370RT SCISSOR LIFT

OPERATING INSTRUCTIONS & SPECIFICATIONS

Unit Specifications

Ground Clearance	13"
Machine Height	9'
Machine Height (Rails Folded)	6' 6"
Machine Length	11'
Machine Width	5' 10"
Machine Weight	7980 lbs
Platform Extension Length	4'
Platform Size - Stowed	5' 2" x 9' 8"
Platform Size - Extended	5' 2" x 13' 1"
Drive System	4 Wheel Drive
Platform Height - Elevated	33'
Working Height	39'
Gradeability	35%
Platform Capacity	1000 lbs