

Z-TURN MOWER HOW TO'S

Roll-Over Protective Structure (ROPS)

- **To Raise ROPS** – On both sides remove the cotter pin from the hitch pin. Pull out the hitch pin on both sides and raise the safety bar. Reinstall hitch pin.
- **To Lower ROPS** - On both sides remove the cotter pin from the hitch pin. Pull out the hitch pin on both sides and fold the safety bar down. Reinstall hitch pin.

Height of Cut Adjustment

- Use the cut height handle, lift the deck to the highest position. Remove the pin from the height selector and place it in the desired height slot. Lower the handle until the deck lever is resting on the pin.

Foot Lift Assist Adjustment

- Remove the knob and top bolt from the pedal. Rotate the pedal to the desired position lining up the hole in the pedal with the square in the arm. Reinstall the bolt and secure with the knob.

Front Deck Lip

- Loosen the front 2 bolts on the deck lip. Adjust the height and then retighten the bolts once you reach your desired height.

Deck Counterbalance Springs

- Raise the cutter deck all the way and latch it in the transport position. Adjust the spring with the nut n the end of the eye-hook. Adjust this if the machine deck is too bouncy leaving an uneven cut.